

AWUS 1900 - Linux Drivers

rtl8814au

Drivers for the rtl8814au chipset wireless adapters

Install Dependencies

```
sudo apt update  
sudo apt install dkms rfkill git iw bc
```

build & install

```
https://github.com/morrownr/8814au  
cd 8814au  
sudo ./install-driver.sh  
# check driver is installed  
find /lib/modules/`uname -r` / -name "8814au.ko"
```

Revision #5

Created 22 March 2025 07:52:30 by tinfoil-hat

Updated 24 March 2025 02:18:56 by tinfoil-hat